ROKU STREAMING STICK: DEVICE SETUP GUIDE



Step #1: Create a Roku Account

Go to <u>https://my.roku.com/signup</u> and fill in all of the required fields.

Create your Roku account You need a Roku account to activate your device and access entertainment across thousands of streaming channels. * First name * Last name * Last name * Email * Email * Password * Password * I am 18 years or older. I agree to the Terms and Conditions. I have read the Privacy Policy. I have read and agree to the Updates and upgrades I have read and agree to the Updates and upgrades I agree to receiving news and special deals from Roku and its partners. I understand that I may withdraw my consent at any time.	
You need a Roku account to activate your device and access entertainment across thousands of streaming channels. • First name * Last name • Email • Email • Password I am 18 years or older. I am 18 years or older. I agree to the Terms and Conditions. I have read the Privacy Policy. I have read and agree to the Updates and upgrades I agree to receiving news and special deals from Roku and its partners. I understand that I may withdraw my consent at any time.	Create your Roku account
 First name Email Email Password I am 18 years or older. I agree to the Terms and Conditions. I have read the Privacy Policy. I have read and agree to the Updates and upgrades I have read and agree to the Updates and upgrades I agree to receiving news and special deals from Roku and its partners. I understand that I may withdraw my consent at any time. 	You need a Roku account to activate your device and access entertainment across thousands of streaming channels.
 Email Password I am 18 years or older. I agree to the Terms and Conditions. I have read the Privacy Policy. I have read and agree to the Updates and upgrades I agree to receiving news and special deals from Roku and its partners. I understand that I may withdraw my consent at any time. 	* First name * Last name
 Password I am 18 years or older. I agree to the Terms and Conditions. I have read the Privacy Policy. I have read and agree to the Updates and upgrades I agree to receiving news and special deals from Roku and its partners. I understand that I may withdraw my consent at any time. 	* Email
I am 18 years or older. I agree to the Terms and Conditions. I have read the Privacy Policy. I have read and agree to the Updates and upgrades I have read and agree to the Updates and upgrades I agree to receiving news and special deals from Roku and its partners. I understand that I may withdraw my consent at any time.	* Password
 I agree to the Terms and Conditions. I have read the Privacy Policy. I have read and agree to the Updates and upgrades I agree to receiving news and special deals from Roku and its partners. I understand that I may withdraw my consent at any time. 	1 am 18 years or older.
I have read and agree to the Updates and upgrades I agree to receiving news and special deals from Roku and its partners. I understand that I may withdraw my consent at any time.	I agree to the Terms and Conditions. I have read the Privacy Policy.
I agree to receiving news and special deals from Roku and its partners. I understand that I may withdraw my consent at any time.	I have read and agree to the Updates and upgrades
	I agree to receiving news and special deals from Roku and its partners. I understand that I may withdraw my consent at any time.
I'm not a robot	I'm not a robot
Continue	Continue
* These fields are required	* These fields are required

Next, confirm your PIN preferences.

Enabling and selecting a PIN passcode will give you an extra level of security for any purchases you may make within the Roku store. If you choose to purchase an app, Roku will automatically ask you to input your PIN passcode to confirm the purchase. This feature is optional and can be adjusted at any time.

loku	
	Choose your PIN preferences
	Setting a Personal Identification Number (PIN) and preference allows you to control when channels can be added and when purchases can be made using your Roku device.
	Always require a PIN to make purchases and to add items from the Channel Store.
	Always require a PIN to make purchases.
	A PIN is not required to make any purchase or add any item from the Channel Store.
	Learn more
	Continue
Language Selector	Terms and Conditions Privacy Policy Developer Site About ads & cookies Roku Inc. 150 Winchester Circle, Los Gatos, CA 95032 www.roku.c
	© 2008-2021 Roku, Ins

Optional: Set Up Roku Pay

Providing a payment method is not required to set-up a Roku account, however if you choose to purchase applications from Roku in the future, Roku Pay is available for a smooth and quick purchasing experience.

Please note: If you choose to add a payment method, WaveDirect will not have access to this information as per the Roku privacy policy. Read the policy <u>here</u>.

If you decide against adding a gayment method, you can go back to the Roku home gage by clicking the logo in the top lot. If you decide against adding a gayment method, you can go back to the Roku home gage by clicking the logo in the top. If you decide against adding a gayment method, you can go back to the Roku home gay by clicking the logo in the top. If you decide against adding a gayment method, you can go back to the Roku home gay by clicking the logo in the top. If you decide against adding a gayment method, you can go back to the Roku home gay by clicking the logo in the top. If you can go back to the Roku home gay back to the row to the top. If you can go back to the row top. If you can go back to the row top. If you can go back to the row top. If you can go back to the row top. If you can go back to the row top. If you can go back to the row top. If you can go back to the row top. If you can go back to the row top. If you can go back to the row top. If you can go back to the row top. If you can go back to the row top. If you can go back to the row top. If you can go back top. If you can you c	Roku	
If you decide against adding a payment method, you can go back to the Roku home page by clicking the logo in the top left corner. Use the top of the top date and update to the top of the top date and update and update of the top date and update and update of the particle subscience.	1	Create your Roku account
If you decide against adding a payment method, you can go back to the Roku home page by clicking the logo in the top left corner.	1	You need a Roku account to activate your device and access entertainment across thousands of streaming channels. * First name * Last name
payment method, you can go back to the Roku home page by clicking the logo in the top left corner.	lf you decide against adding a	* Email
 I am IB years or older. I am IB years or older. I are read and agree to the Updates and upgrades I are read and agree to the Updates and upgrades I are read and agree to the Updates and upgrades I are read and agree to the Updates and upgrades I are read and agree to the Updates and upgrades I are read and agree to the Updates and upgrades I are read and agree to the Updates and upgrades I are read and agree to the Updates and upgrades I are read and agree to the Updates and upgrades I are read to the part of the par	payment method, you can go back to the Roku home page by clicking	• Password
Interlog of interlog I define rog of interlog I define rog of interlog of		I am 18 years or older. I agree to the Terms and Conditions. I have read the Privacy Policy.
Im not a robot Margin Stress Continue * These fields are required I already have a Roku account. Sign in	left corner.	 I have read an agree to the oppoales and opprades I agree to receiving news and special deals from Roku and its partners. Understand that I may withdraw my consent at any time.
* These fields are required I already have a Roku account. Sign in		fm not a robot
l aiready have a Roku account. Sign in		Continue These fields are required
		I already have a Roku account. Sign in

From the Roku homepage you can view your account and settings



Step #2: Getting started and connecting in your Roku Streaming Stick

What's included in your Roku Steaming Stick package?





First, plug your Roku Streaming Stick into the HDMI port of your TV. Next, use the USB power cable, power extender cable, and power adaptor to connect your device to an outlet.



Alternatively, you can use the included USB power cable to power your device from the USB port on your TV.

Note: The USB port on some TV's may be unable to power your device. If you see the on-screen warning message that appears in these cases, use a wall outlet.



Next, power on your TV and select the correct input.



After you've selected the correct input, insert the batteries into the Roku Streaming Stick remote and begin the pairing process.



Follow the on screen instructions to pair your remote to your streaming stick.



Once paired, you will see this setup screen to get started with your preferences.



After clicking your language choice, your device will need to connect to your home WiFi network.



Choose your home network and input your WiFi password.

Once your device establishes a network connection, you will be promted to set up your display type.

*You may notice that your Roku requires an update, click okay and allow it to continue.



Click "Auto detect display type", once completed click "Use automatic" and click "Yes, screen looks good".



Set up your Roku remote. Click check the remote settings. You will be asked if you want to set up your Roku remote to control the power and volume on your tv, click continue.



Step #3: Link your device

During the set-up on your TV you will be asked to log into your Roku account.



You need to pair your Roku account with your device. Click enter your email address.

Next, check your email inbox for your email activation link.

Once you click the activation link in your email, you will be asked to name your device and identify its location. Agree to the terms and select continue. You will now be able to add other favourite applications at this time. You can also choose to do this later. (See setup video for full visual demonstration)

Once updated, you should now see on screen prompts on your tv followed by the Roku demonstration.



When you're device is successfully linked, you can move onto the Step #4.

Step #4: Install the NorthWaveTV app



To access the updated version of the app, you can follow **one of two steps**:

1. From the Roku homepage, hold the microphone button and say *NorthWave* into the remote.

When the app appears, click it, select *"Add channel"*, agree to the terms and NorthWaveTV will download to your homepage.

OR

2. From the Roku homepage, click "+ Add Channels" and search for **NorthWaveTV** by typing it into the search engine. Select the app, agree to the terms and the channel will download to your homepage.





Once the app has downloaded, you can select *"Go to channel"* or click the home button on your remote to view the app on your homepage. Hom

Select the app and proceed to the next final step to connect to NorthWaveTV.

Step #5: Log-in and Start Streaming!

Click the NorthWaveTV app and then log in using the information provided in the email we sent you.



You're ready to start streaming NorthWaveTV!

For support, please contact your Internet Service Provider

